

SOUTHERN ICE and COOL ICE slip set up.

Southern Ice and Cool Ice slip will become less fluid with age due to changes in the available defloculant.

To modify the fluidity:

1. Add 10 mls of sodium silicate to 100 mls of water and mix.
2. Thoroughly mix the slip, without introducing air bubbles.
3. If the slip is too thick add 10 mls of the sodium silicate water mixture and thoroughly mix.
4. Repeat additions of the sodium silicate water mixture until the desired fluidity is achieved.