

Making slip from SWE Plastic Clay.

You will need:

- 1 pack of SWE plastic clay (approx. 10 kg)
- 1.75 litres water.
- 15 grams Sodium Silicate.
- 5 grams Soda Ash.
- 9 grams Dispex.
- A method of mixing i.e. a small blunger.

Process:

1. Take a small amount of water and warm it. Dissolve the Soda Ash and Sodium Silicate in it. Add this back into the rest of the water.
2. Shred SWE and progressively add it to the mixture, a small amount at a time whilst blunging, until it is homogeneously mixed.
3. Then slowly add the Dispex until you get the required slip density and viscosity.

Please note:

- As conditions vary in different workshops and studios, it is recommended that comprehensive testing be done to insure suitability.